

FitRx™

Smart Food Scale

User Guide

Welcome to the FitRx fam!

Sleek, convenient, and effortless food scale for your hectic journey to wellness. Getting healthy has never been so easy with the FitRx Smart Food Scale!

Features

- Highly precise gauge sensor
- Tare function
- Touch On/Off
- Overload and low power indication
- Auto power off
- Batteries included

Diagram

1. LCD Digital Screen
2. On/Off button
3. Unit button
4. Stainless steel surfaces



Instructions and Specifications on other side

relieve. recover. relax.

Instructions

1. Open the back cover and insert 2 AAA batteries.
2. Place the scale on a flat and hard surface.
3. Touch the 'Power/Tare' button to turn the scale ON.
4. Touch the 'Unit' button to cycle between the Grams, Kilograms, Ounces and lb. modes.
5. Place the food in the center of the scale for more accurate results.
6. Touch and hold the 'Power/Tare' button to turn the scale OFF. The scale will automatically turn OFF after 60 seconds of inactivity.

Using Containers

1. To measure food using containers, place the container on the center of the scale.
2. Touch the 'Power/Tare' button to reset the scale to 0.
3. Place the food to weigh inside the container.

Overloading Indicator

If food scale has reached max capacity of 11lb (5kg), the LCD screen will show "EEEE"

Low Power Indicator

When LCD screen displays "LO", open back battery cover and replace batteries.

Specifications

Battery: 2X AAA batteries.

Units measurement: g/kg/oz/lb'oz

Minimum Weighing: 0.07oz (2g)

Maximum Weight: 11lb. (5kg)

For more details on the FitRx family of products or to check out more brilliant innovations visit tzumi.com



FitRx Smart Food Scale Item No. 8304. ©Copyright 2021. All Rights Reserved. Made In China.
All other trademarks and tradenames are the property of their respectful owners. All pictures shown are for illustration purpose only. Actual product may vary due to product enhancement.
Subject to change without prior notice.